



AG100-AG500



AG600



AG1000-AG4000,AG8

# USER MANUAL

AG SERIES

**Contents:**

1. General description .....	3
2. Completeness .....	3
3. Balance description .....	4
4. Keys and indicators .....	6
5. Technical data .....	7
6. Security rules.....	8
7. Preparations – working environment .....	9
8. Preparations – the balance.....	10
9. Operation principles.....	11
10. Start-up .....	12
11. Internal calibration .....	13
12. User functions menu.....	14
12.1 Autotaring .....	15
12.2 Pieces counting function .....	16
12.3 External calibration / calibration options.....	18
12.4 RS-232C interface setting.....	21
12.5 Print-out settings.....	22
12.6 Date and time setting .....	25
12.7 LCD settings .....	26
12.8 Language setting (option) .....	27
12.9 Weigh summing (option) .....	28
12.10 Maximal /minimal value (option).....	29
12.11 Treshold signalization (option) .....	30
13. Connecting the balance to computer or printer .....	34
14. Troubleshooting and maintenance .....	35
Declaration of Conformity.....	36

## **1. General description**

AG series balances are destined for high accuracy weighing in laboratory practice.

Balances are equipped with internal calibration system for proper accuracy control during operation. The user should also own weight standard of OIML F2 or F1 class for periodical control of the balance (weight value stated in Technical Data sheet) - available for extra fee.

All balances are metrologically tested - calibration or legal verification certificate on demand.

Legal verification is required for balances used in some applications: direct sale, pharmaceutical prescriptions, medical and pharmaceutical analysis, goods packing and others.

Balances with legal verification are mark with the following:

- protective seal placed on the casing mounting screw at the back of the balance,
- calibration switch protective seal,
- notified body stamps and green metrological marking placed on the balance name plate.

AGZ series balances are destined for purposes where verification is not required. AGZ series balances do not have internal calibration system and also all functions connected with it are removed (chapter 11 and 12.3).


## **2. Completeness**

A standard set consist of:

1. Balance
2. Pan elements:
  - AG50-AG600 (round pan): a pan base and a pan,
  - AG1000-AG4000, AG8 (rectangular pan): gum nuts (4pcs) and a pan,
3. Feeder (ZN12V/500mA)
4. User manual
5. Guarantee Card

### 3. Balance description

Front view (AG100-AG600)




- 1 – pan
- 2 – pan support
- 3 – pan ring
- 4 – LCD display
- 5 – keys
- 6 – rotating legs
- 7 – water level
- 8 – antiblast shield

**Note:**


AG600 does not have the pan ring and the antiblast shield.

Front view (AG1000-AG4000, AG8)




- 1 – pan
- 2 – pan supports
- 4 – LCD display
- 5 – keys
- 6 – rotating legs
- 7 – water level

Rear view:



## 4. Keys and indicators




keys	→T←	-	tare (subtract package weight from weighed mass)
key	I/⏻	-	switch-off (standby),
key	ENTER	-	confirm
key	.	-	decimal point,
key	1/F1 ... 5/F5	-	numeric / functional keys,
key	6/→0←	-	numeric key / zeroing (balances for direct sale use only),
key	7/□	-	numeric key / data output (print / transmission),
key	8/▼	-	numeric key / internal calibration,
key	9/MENU	-	numeric key / Menu,
key	0/↺	-	numeric key / special function,
key	>	-	enter an option,
key	<	-	leave an option,
key	^	-	navigation / move a cursor up,
key	v	-	navigation / move a cursor down,
indicator		-	result stabilisation,
indicator	linear	-	total load indicator (0-100%),
indicator	OFF	-	stand-by mode,
Max, Min, d, e, II		-	metrologic parameters and accuracy class.

## 5. Technical data

Type	AG100	AG200	AG300	AG500
Capacity (Max)	100g	200g	300g	500g
Min load (Min)	0,02g	0,02g	0,02g	0,02g
Reading unit (d)	0,001g	0,001g	0,001g	0,001g
Verification unit (e)	0,01g	0,01g	0,01g	0,01g
Tare range	-100g	-200g	-300g	-500g
Accuracy class	II			
Working temperature	+18 ÷ +33°C			
Weighing time	<8s			
Pan dimension	φ115mm			
Balance base dim.	215(235)x345x90mm			
Balance weight	5kg			
Power	~230V 50Hz 6VA / =12V 300mA			
Calibration weight (OIML)	100g F2	200g F2	200g F2	500g F1

Type	AG600	AG1000	AG2000	AG3000	AG4000	AG8
Capacity (Max)	600g	1000g	2000g	3000g	4000g	8000g
Min load (Min)	0,5g	0,5g	0,5g	0,5g	0,5g	5g
Reading unit (d)	0,01g	0,01g	0,01g	0,01g	0,01g	0,1g
Verification unit (e)	0,1g	0,1g	0,1g	0,1g	0,1g	1g
Tare range	-600g	-1000g	-2000g	-3000g	-4000g	-8000g
Accuracy class	II					
Working temperature	+18 ÷ +33°C					
Weighing time	<5s					
Pan dimension	φ150mm	165x165mm				
Balance base dim.	215(235)x345x90mm					
Balance weight	5kg					
Power	~230V 50Hz 6VA / =12V 300mA					
Calibration weight (OIML)	500g F2	1000g F2	2000g F2			5000g F2

## 6. Security rules






To avoid electrical shock or damage of the balance or connected peripheral devices, it is necessary to follow the security rules below.

- All repairs and necessary regulations can be made by authorised personnel only.
- To avoid fire risk use a feeder of an appropriate type (supplied with the balance). Pay attention that supply voltage is compatible with specified technical data.
- Do not use the balance when its cover is opened.
- Do not use the balance in explosive conditions.
- Do not use the balance in high humidity.
- If the balance seems not to operate properly, unplug it from the mains and do not use until checked by authorised service.



## 7. Preparations – working environment




When choosing a location to set up the balance, remember the following rules to ensure proper working conditions and user-friendly operating:


- setup the balance on an even, flat surface leaving necessary room for easy access,
- maintain proper working temperature,
- avoid strong air drafts, vibrations, dust, big temperature changes and humidity over 90%,
- avoid locations with extreme heat radiation and electromagnetic or magnetic fields.

## 8. Preparations – the balance

1. Take the balance and supplied accessories (a feeder, pan elements) out of the box.
2. Place the balance on a stable ground not affected by mechanical vibrations and airflows.
3. Level the balance with rotating rear legs 6 so that the air bubble in water-level 7 at the back of the balance is in the middle.
4. (for AG100-AG600) Gently insert the mandrel of pan support 2 into pan socket through the pan ring 3. Put the decorative pan 1 on (AG600 balances have decorative pan joined with pan support).



5. (for AG1000-AG8) Place supports 2 on mandrels visible in balance cover hole put pan 1 on supports.



6. Plug a feeder to the power socket at the back of the balance.



Moisture in the air may condense on the surface of the balance when transferred to the warmer environment. In this case leave the balance for at least 4 hours unplugged from the mains for conditioning to avoid wrong operating or damage of the balance.

Leave the pan empty and plug the feeder to the mains. At the end of self-tests, the balance displays zero indication and is now ready to work.

## **9. Operation principles**

1. To ensure proper weighing accuracy the balance is equipped with internal calibration system. The system automatically calibrates the balance every 2 hours and with temperature changes (more than 1°C) without user interference. Nevertheless, it is advised to check balance accuracy with weight standard (or other object with known weight) before and after each series of measurements.
2. Weighed sample should be placed in the centre of the pan.
3. In direct sale use (d=e), make sure that zero indicator is displayed. If not, press  $\rightarrow 0 \leftarrow$  key and wait until zero indication and zero indicator appears. In other balances the key does not operate.
4. The balance is equipped with a tare equal to its range. To tare the balance press  $\rightarrow T \leftarrow$  key. Storing a tare value does not extend measuring range, but only subtracts it from a load placed on a pan. To make weight control easier and to avoid range overdrawn, the balance is equipped with a load indicator (graduated in percentages).
5. Weighing result should be read when the indicator " $\blacktriangle \blacktriangle$ " lights, which signals stabilisation of a result.
6. When the balance is not used but it is necessary to be ready to work immediately, it can be switched off by pressing  $I/\phi$  key. The balance reading system is then switched off to "standby" mode (signalled by the indicator "OFF"). To switch the balance on press  $I/\phi$  key. The balance is immediately ready to operate maximum accuracy (after self tests).

7. The mechanism of the balance is a precise device, sensitive to mechanical strokes and shocks.

Before transportation take off the pan (move it slightly and lift it up) and the pan base and preserve from any damages.




Do not overload the balance more than 20% of maximum load (Max).


Do not press a pan with a hand.

8. The balance should not be used to weigh ferromagnetic materials due to accuracy decrease.
9. When the balance is moved to another localisation remember to level the balance and proceed with internal calibration.


## 10. Start-up



After switching-on, the balance performs automatic self-test. Each test must be accepted and confirmed with ✓ mark.



After self-test the balance proceeds with internal calibration mode as described in chapter 11.




When internal calibration is finished, the balance is in normal weighing mode.


## 11. Internal calibration

Internal calibration is performed automatically after each start-up, also every 2 hours and with temperature changes more than 1°C.



To calibrate the balance with internal weight, simply empty the pan and press ▼ key twice.



Press ▼ key twice.



Until calibration process is finished do not perform any operation, as any vibrations and shocks may affect the process of calibration and delay the calibration or deteriorate the result.



The calibration weight is placed on the pan three times to avoid inaccurate calibration result. In case any problems during calibration, the error is signalled on the display and calibration process is stopped. The result of correct calibration is zero indication.

In case internal calibration does not ensure proper accuracy of the balance (e.g. results of weighing object of known weight are wrong), please contact the nearest service centre.

## 12. User functions menu

All balances, beside basic functions like weighing and tare, are equipped with additional functions. Basic set of special functions is shown below. In respect of metrology calibration with external weight is important special function.

Other functions: recipe ingredients summing, density calculation etc. can be enabled as an option on customer request (described in additional brochure when ordered).

USER FUNCTIONS&OPT.	
<input checked="" type="checkbox"/>	Autotaring
<input type="checkbox"/>	PCS counting
<input type="checkbox"/>	Unit selection
<input type="checkbox"/>	Percent
<input type="checkbox"/>	Calibration
<input type="checkbox"/>	RS-232C settings
<input type="checkbox"/>	Print settings
<input type="checkbox"/>	Time&date settings
<input checked="" type="checkbox"/>	LCD settings
<input type="checkbox"/>	Menu settings
	Exit

To enter the user menu press *Menu* key. The cursor (dark background) is placed at the top.

To move the cursor, use the navigation keys: ▼ and ▲.

☒ - function activated

☐ - function deactivated

To enter chosen function and open the menu of the function press *ENTER* key.

To return to the previous window press < key. To leave the user menu and return to weighing mode choose *Exit* option.

USER FUNCTIONS&OPT. / ENABLING	
✓	Autotaring
✓	PCS counting
	Unit selection
	Percent
	Calibration
✓	RS-232C settings
	Print settings
	Time&date settings
	LCD settings
	Menu settings
	Exit


Easy access to the most useful functions will shorten operation time and make work more comfortable. To remove a function from the function menu, use *Menu settings* option.

Select function by cursor and press *ENTER* key. Chosen functions should be signified with ✓ mark.


To quickly go from functions menu to Menu settings press ↺ key.

## 12.1 Autotaring

This function automatically keeps zero indication when a pan is empty or zero indication was forced with  $\rightarrow T \leftarrow$  key.




Press *Menu* key to enter the user function menu, choose *Autotaring* and press *ENTER* key.




Choose *Correction range* using  $\vee$  and  $\wedge$  keys and press *ENTER* key.

Enter maximum zero flow to be automatically corrected (choose between  $0.5 \div 5$  verification unit(s) per second).



Choose *Activate* option and press *ENTER*.




Any changes off the zero readout that are equal to a defined fraction of digits per second are automatically tared, independently of changing environment conditions (temperature, humidity, etc.).


To leave the function press *Menu* key, choose *Autotaring* function and then choose *Deactivate* option.

## 12.2 Pieces counting function


### 1. Counting with a reference sample




Place a reference sample with known number of pieces on the pan.




Press *Menu* key to enter the user function menu, choose *Counting* with the cursor and press *ENTER* key.



Chose *Pieces quantity* option and press *ENTER* key.



Using numeric keys enter the quantity of the sample and press *ENTER* key.



The balance calculates unit weight basing on given number of pieces and reference sample weight and then shows number of pieces on the display.


Reference sample parameters may be used in series of weighing. To recall previously used sample parameters start Counting function with *Activate* option. To leave the function press *Menu* key, choose *Counting* function and then choose *Deactivate* option.

#### Note:


To switch between weighing mode and pieces counting mode press ↺ key.




## 2.Counting with unit weight.




Press *Menu* key to enter the user function menu, chose *Counting* and press *ENTER* key.



Chose *Unit weight* option and press *ENTER* key.



Enter unit weight value using numeric keys and press *ENTER* to accept. The unit weigh value is stored in balance memory until switched off.



The balance displays pieces amount.


**Note:** To correct wrong digits when entering unit weight, press *<* key to delete the last number or *CLR* to leave the function and proceed from the beginning.

## 12.3 External calibration / calibration options

Calibration with external weight standard in verified balances should be performed in case balance indications exceed permissible error. To calibrate the balance a service centre should use calibration weight as stated in Technical Data table (or of better accuracy) with valid calibration certificate.



Calibration of EC verified balance requires to destroy a mark for protecting an access to adjustment switch and results in losing its EC verification. To renew EC verification of a balance, contact with service or notified body is necessary.



In EC verified balances executing a calibration requires to change adjustment switch position, which is placed behind the mark (sticker) of a notified body. An access to the switch is possible only after the mark is removed, which causes losing EC verification of the scale. To renew EC verification of a balance, contact with service or notified body is necessary.

In order to store results of calibration with external weight it is possible to print calibration report (see Calibration options). For this purpose a printer or a computer with testing program is necessary.

The report printout example

Date : ... Time: ...

Calibration report

Date of production: ...

Serial number: ...

Program version: ...

Adjustment no.: ...

Factory external weight: ...

- external weight value registered during factory calibration

Factory internal weight: ...

- internal weight value registered during factory calibration

Current external weight: ...

- external weight value registered during last calibration

Current internal weight: ...

- internal weight value registered during last external calibration

Weight difference: ...

- difference between internal weight values: factory value–current value

**Calibration options:**

USER FUNCTIONS	
<input type="checkbox"/>	Autotaring
<input type="checkbox"/>	PCS counting
<input checked="" type="checkbox"/>	Calibration
	...

USER FUNCTIONS \ CALIBRATION	
1.	External calibration
2.	External load : <u>200g</u>
3.	Calibration of time : 2h
4.	Calibration of temp. : 1.0°C
5.	Report printout
6.	Exit

USER FUNCTIONS \ CALIBRATION	
1.	External calibration
2.	External load : <u>200g</u>
3.	Calibration of time : 2h
4.	Calibration of temp. : 1.0°C
5.	Report printout
6.	Exit

USER FUNCTIONS \ CALIBRATION	
1.	External calibration
2.	External load : <u>200g</u>
3.	Calibration of time : 2h
4.	Calibration of temp. : 1.0°C
5.	Report printout
6.	Exit

If an access to adjustment switch is not protected with the mark, with a thin screwdriver set adjustment switch to ON position (balance displays the message *Calibration switch ON* and makes a sound).

Press MENU key choose *Calibration* option and press ENTER.

Option *External weight* enables to enter the value of used calibration weight. Choose *External weight* option, press ENTER and use > and < keys to select desired value. It is advised to use as great weight value as possible.

*Calibration of time* and *Calibration of temperature* option is related with internal calibration.

To print a calibration report, connect a printer and use *Report printout* option. Calibration report is a proof of correct calibration process and may be useful for balance diagnostics.

**Calibration sequence:**


USER FUNCTIONS	
<input type="checkbox"/>	Autotaring
<input type="checkbox"/>	PCS counting
<input checked="" type="checkbox"/>	Calibration

Press *Menu* key, choose *Calibration* option and press *ENTER* to accept (calibration must be enabled).


USER FUNCTIONS \ CALIBRATION	
1. External calibration	
2. External load	: 200g
3. Calibration of time	: 2h
4. Calibration of temp.	: 1.0°C
5. Report printout	
6. Exit	

Check if *External weight* value is equal to external weight value used for calibration. If not, choose *External weight* option and enter correct value.


Choose *External calibration* option and press *ENTER* to accept.

CALIBRATION	
	External calibration: taring


Wait until taring process is finished and load the pan with the calibration weight of correct value.

CALIBRATION	
	External calibration: Put the calib. weight 200g

Take off the calibration weight.

CALIBRATION	
	External calibration: Remove calib. weight

Wait until external calibration is finished.

CALIBRATION	
	External calibration: wait



Max ...	Min ...	e= ...	d= ...
0.000 g			
0%	<div style="width: 100%; height: 10px; border: 1px solid black;"></div>		100%

After external calibration the balance switches to the weighing mode.

## 12.4 RS-232C interface setting

To enable cooperation with a printer (or a computer), transmission parameters must be equal in both devices.

This function enables the following transmission parameters:

- send and receive speed (1 200 ÷ 115 200bps),
- number of bits (7 or 8 Bytes),
- parity control (none, even, odd),
- protocole type (default protocole - LONG),
- transmission mode (after  / *PRINT* key pressing with stable indication, directly after  / *PRINT* key pressing without stable indication, automatically after stabilisation of each weighing result, continuous transmission in 0,1s periods).

USER FUNCTIONS	
<input type="checkbox"/>	Autotaring
<input type="checkbox"/>	PCS counting
. . .	
<input checked="" type="checkbox"/>	RS-232C settings
. . .	

Press *MENU* key to enter the user function menu, choose RS232C settings and press *ENTER* key.

USER FUNCTIONS / RS232C SETTINGS	
1. Baudrate:	4800
2. Bits:	8-bit
3. Parity:	brak
4. Protocol:	LONG
5. Sending mode:	button+stab.
6. Exit	

Check if balance RS232C interface transmission parameters are compliant with connected external device parameters.

To enter correct parameters values select desired parameter using  $\vee$  and  $\wedge$  keys and press *ENTER* key.

USER FUNCTIONS / RS232C SETTINGS	
1. Baudrate:	<4800>
2. Bits:	8-bit
3. Parity:	brak
4. Protocol:	LONG
5. Sending mode:	button+stab.
6. Exit	

Set correct parameter value using  $<$  and  $>$  keys and press *ENTER* to accept.

To leave the function press *MENU* key or use *Exit* option.

## 12.5 *Print-out settings*

This function enables to select desired information, which will be used on print-outs:

- numeration of successive measurements,
- date and time of each measurement,
- custom information (optional) – additional text entered with a computer keyboard.

USER FUNCTIONS

☐ Autotaring

☐ PCS counting

. . .

☒ **Print settings**

. . .

Press *MENU* key to enter the user function menu, choose *Print settings* and press *ENTER* key.

USER FUNCTIONS \ PRINT SETTINGS

☐ Header

☐ Values

☐ Footer

☐ ID1

☐ ID2

☐ ID3

☐ Exit

Select desired parameter using  $\downarrow$  and  $\uparrow$  keys and press *ENTER* key to change setting.

**Header** - the entrance to the printout header definition menu; the checkbox sign indicates if at least one option in the header definition menu is marked.

### *Header definition menu*

USER FUNCTIONS \ PRINT SETTINGS

☐ Blank line

☐ Mode name

☐ Date & time

☐ Balance type

☐ Serial number

☐ ID1

☐ ID2

☐ ID3

☐ Signature

☐ Exit

Relevant element is marked/unmarked if *ENTER* key is pressed. The marked element will appear in a printout header if the *Header* element in values definition menu is marked.

An example of a full printout header:

----- WEIGHING -----	← blank line
Date : 2000-04-25                      Time : 22:32	← mode name
Scale type                                : AGNZ200	← date and time
Serial number                            : 123456	← balance type
ID1 string	← serial number
ID2 string	← ID1
ID3 string	← ID2
Signature	← ID3
.....	← signature

**Values** - the entrance to printout values definition menu; the checkbox sign indicates if at least one option in values definition menu is marked.

### Values definition menu

**USER FUNCTIONS \ PRINT SETTINGS**

☐ Header

☐ Blank line

☐ ID1

☐ ID2

☐ ID3

☐ Measur. Number

☐ Tare

☐ Net

☐ Gross

☐ LCD result

Exit

Relevant element is marked/unmarked if *ENTER* key is pressed. The values *Tare*, *Net* and *Gross* are always expressed in grams. The value *LCD result* always indicates display state with an active unit.

An example of a full printout header (without header):

ID1 string	← blank line
ID2 string	← ID1
ID3 string	← ID2
Measurement number : 1	← ID3
T            0.0000    g	← measurement number
N            66.7425   g	← tare
B            66.7425   g	← net
LCD        333.7125   ct	← gross
	← LCD result

**Footer** - the entrance to the printout footer definition menu; the checkbox sign indicates if at least one option in footer definition menu is marked.

### *Footer definition menu*

USER FUNCTIONS \ PRINT SETTINGS	
<input type="checkbox"/>	Blank line
<input type="checkbox"/>	Mode name
<input type="checkbox"/>	Date & time
<input type="checkbox"/>	Balance type
<input type="checkbox"/>	Serial number
<input type="checkbox"/>	ID1
<input type="checkbox"/>	ID2
<input type="checkbox"/>	ID3
<input type="checkbox"/>	Signature
<input type="checkbox"/>	Dash line 3
<input type="checkbox"/>	3 blank lines
	Exit

Relevant element is marked/unmarked if *ENTER* key is pressed.

An example of a full printout footer :

----- PCS COUNTING -----	← blank line
Date : 2000-04-25                      Time : 23:05	← mode name
Scale type                                : AGNZ200	← date and time
Serial number                            : 123456	← balance type
ID1 string	← serial number
ID2 string	← ID1
ID3 string	← ID2
Signature	← ID3
.....	← signature
-----	← separating line
	← 3 empty lines

**ID1, ID2, ID2** - strings (max. 20 characters) defined by PS2 keyboard or by a scale numeric keypad, which works similarly to mobile keyboard (characters coupled with relevant key appear in a display first line after the key is pressed); inscribed string is approved with ENTER key.



## 12.6 Date and time setting

Use this function to set current date and time, used in print-outs:

USER FUNCTIONS	
<input type="checkbox"/>	Autotaring
<input type="checkbox"/>	PCS counting
. . .	
<input checked="" type="checkbox"/>	Time&date settings
. . .	

Press *MENU* key to enter the user function menu, choose *Time&date settings* and press *ENTER* key.

USER FUNCTIONS \ DATE AND TIME	
1. Time:	09:11:03
2. Date:	2006-03-31
3. Exit	


Select desired parameter using  $\downarrow$  and  $\uparrow$  keys and press *ENTER*.

USER FUNCTIONS \ DATE AND TIME	
1. Time:	09:11:03
2. Date:	2006-03-31
3. Exit	


Enter correct values using numeric keys and press *ENTER* to accept.

## 12.7 LCD settings


This function enables to set contrast and back-light illumination of the LCD display:




Press *MENU* key to enter the user function menu, choose *LCD settings* and press *ENTER* key.




Choose *Contrast* option using  $\nabla$  and  $\wedge$  keys and press *ENTER* to key.



Select desired Contrast value using  $<$  and  $>$  keys and press *ENTER* accept.



Choose *Backlight* option using  $\nabla$  and  $\wedge$  keys and press *ENTER* key.



Turn LCD *Backlight* on or off and press *ENTER* to accept.

## 12.8 Language setting (option)

This function enables to select a language used for displayed comments and printouts:

USER FUNCTIONS

☐ Autotaring

☐ PCS counting

...

☒ Language settings

...

Press *MENU* key to enter the user function menu, choose *Language settings* and press *ENTER* key.

USER FUNCTIONS \ LANGUAGE SETTING

1. Polish

2. English

3. German

4. Russian

5. Ukrainian

6. Spanish

7. French


8. Czech

9. Exit


Select desired language using  $\wedge$  and  $\vee$  keys and press *ENTER* key to accept

## 12.9 Weigh summing (option)


This function allows separate weighing of several ingredients in one container with a possibility to control aggregated sum of all weighed components.



Press **Menu** key, choose *Weighs summing* and press **ENTER** to accept.




Chose *Activate* option using **▼** and **▲** keys and press **ENTER**.



The balance is now ready for successive ingredients weighing.

Before weighing each ingredient press **→T←** key to zero the indication.

During series weighing total weight ( $\Sigma$ ) and number of series (n) are shown at the left of the display.




For instant return to weighing mode and display total weight of all ingredients press **↺↻** key. To return to series summation press the key again.


To leave the function press **Menu** key, chose *Weigh summing* function and then chose *Deactivate* option.

## 12.10 Maximal /minimal value (option)


This function enables to display a maximal or minimal value of series of weighing.




Press **Menu** key, choose *Maximal/minimal value* and press **ENTER** to accept.



Choose *Activate* option using **▼** and **▲** keys and press **ENTER**.



The function is now active – the balance displays only maximum value from successive series of weighing (starting from the function activation or using *Reset* option).



To display weigh value of a current sample press **↺** key. To return to Maximum value function press the key again.

To leave the function press **MENU** key, choose *Maximal/minimal value* function and then chose *Deactivate* option.

## 12.11 Threshold signalization (option)

This function compares weighing result with two reference values: lower and upper threshold. The balance signalises comparison result with MIN, OK and MAX indicators and sound signal.

If comparison result is:

- smaller than lower threshold – the balance displays MIN,
- between threshold values - the balance displays OK,
- bigger than upper threshold - the balance displays MAX
- lower than zero threshold (no load) – none of the indicators appears

### Operation sequence:

USER FUNCTION	
<input type="checkbox"/>	Autotaring
<input type="checkbox"/>	PCS counting
...	
<input checked="" type="checkbox"/>	Threshold signalization

Press *MENU* key, choose *Threshold signalization* option and press *ENTER* to accept.

USER FUNCTION \ TRESHOLD SIGNAL.	
1. Activate	
2. Zero threshold:	brak
3. MIN threshold:	none
4. MAX threshold:	none
5. Outputs mode:	none
6. Buzzer :	none
7. Wyjście	

Chose *Zero threshold* option using  $\nabla$  and  $\wedge$  keys and press *ENTER*.

USER FUNCTION \ TRESHOLD SIGNAL.	
1. Activate	
2. Zero threshold:	5
3. MIN threshold:	none
4. MAX threshold:	none
5. Outputs mode:	none
6. Buzzer :	none
7. Exit	

Enter *Zero threshold* value using decimal keys and press *ENTER* key – indications below this value are regarded as unloaded balance (threshold indicators does not appear).

USER FUNCTION \ TRESHOLD SIGNAL.	
1. Activate	
2. Zero threshold:	5
3. MIN threshold:	12.000
4. MAX threshold:	none
5. Outputs mode:	none
6. Buzzer :	none
7. Exit	

Enter *MIN threshold* and *MAX threshold* values.

*Outputs mode* enables to set *THRESHOLD* output working mode (described further). To choose appropriate working mode use  $<$  and  $>$  keys and press *ENTER* key to accept.

## USER FUNCTION \ TRESHOLD SIGNAL.

1. Activate
2. Zero threshold: 5
3. MIN threshold: 12.000
4. MAX threshold: none
5. Outputs mode: none
6. Buzzer : <stable OK>
7. Exit



*Buzzer* option enables to select sound signal mode. When *Stable OK* option is set, sound signal occurs after weighing result stabilisation within OK range. Other possible options:


- sound signal occurs when threshold values (MIN and MAX) are exceeded,
- no sound signal

## USER FUNCTION \ TRESHOLD SIGNAL.

1. Activate
2. Zero threshold: 5
3. MIN threshold: 12.000
4. MAX threshold: none
5. Outputs mode: none
6. Buzzer : <stable OK>
7. Exit



To start function choose *Activate* option and press *ENTER* key.



After each measurement the balance displays comparison result.

## USER FUNCTION \ TRESHOLD SIGNAL.

1. Deactivate
2. Zero threshold: 5
3. MIN threshold: 12.000
4. MAX threshold: none
5. Outputs mode: none
6. Buzzer : <stable OK>
7. Exit




To leave the function press *MENU* key, choose *Threshold signalization* function and then choose *Deactivate* option.

In balances equipped with *THRESHOLD* output, comparison result may be used to control external optical indicator or other external devices.


Threshold comparison results appear on *Thr I* and *Thr II* output pins as a shortcircuit state. Control output working modes are presented on the state charts below.

## THRESHOLD output state charts (increasing load):


### 1. *Indicator* mode:



### 2. *Pulse* mode:



### 3. *Level* mode:







*THRESHOLD* output is a open collector transistor output with load capacity 100mA / 24V. Additional transmitters require separate 24V feeder, transmitter input must be protected with diodes, e.g. 1N4148.

AXIS offers MS3K/P electronic board, consisting of RM96P transmitters, with DC24V input voltage and AC250V, 8A output (sold separately).

*PROGI* output




Single transmitter connection



### 13. Connecting the balance to computer or printer

The balance may send data to a computer or a printer via RS232C interface.



When cooperating with a computer, the balance sends weighing result after initialising signal from a computer or after pressing  $\overline{\text{E}}$  key.

When cooperating with the balance, a computer should be equipped with a program that enables receiving and processing data from the balance.

AXIS offers computer programs to cooperate with balances. Demo versions and program descriptions are available on the website: [www.axis.pl](http://www.axis.pl):

- RS 232C Test – free serial port testing program,
- ProCell – residual program for cooperation with Microsoft EXCEL and other Microsoft Windows applications (demo version).

*Detailed information for programmers:*

*The balance sends data with a following method:*

*Computer → Balance: initiation signal S I CR LF (53h 49h 0Dh 0Ah),*

*Balance → Computer: weighing result in the following format:*

*(16Bytes, LONG protocol - 8bits, 1stop, no parity, 4800bps),*

*Bytes description:*

- 1 - „-, mark or space
- 2 - space
- 3÷4 - digit or space
- 5÷9 - digit, decimal point or space
- 10 - digit
- 11 - space
- 12 - k, l, c, p or space
- 13 - g, b, t, c or %
- 14 - space
- 15 - CR
- 16 - LF

## 14. Troubleshooting and maintenance

Display indication	Possible cause	Remedy
"Test ..."	Auto-tests are being performed / electronic unit damage	wait for 1 minute
" - - - - "	The balance is during zeroing / mechanical damage	wait for 1 minute check if the balance is placed on stable ground, not affected by vibrations
"Internal calibration: load error"	To small zero load or overloading of balance mechanism / mechanical damage	Check if there are all necessary pan elements or if the balance is not loaded
„Tare range exceeded"	Tare key pressed during zero indication	Balance indications must be different than zero
„Zeroing range exceeded"	Permissible zeroing range was exceeded	Remove the load from the pan
„Weighing range exceeded"	Permissible weighing range (Max +9e) was exceeded	Reduce the load
„Measuring range exceeded (+)"	Upper limit of analog-digital transducer measuring range was exceeded	Remove the load from the pan
„Measuring range exceeded (+)"	Lower limit of analog-digital transducer measuring range was exceeded	Check if there are all necessary pan elements
„Unit weigh is too small"	Entered unit weigh is too small	Unit weight is too small or entered number of pieces is too big

If a remedy does not have any effect and the communicate is still displayed, contact your dealer or service centre.

1. A balance should be kept clean.
2. Take care that no dirt gets between the casing and the pan. If found any, remove a pan (lift it up), remove the dirt and then replace a pan.
3. In case of improper operation caused by a short-lasting power supply decay, unplug the balance from the mains and then plug it in again after few seconds.
4. It is forbidden to make any repairs by unauthorised persons.
5. To repair a balance, please contact our nearest service centre.

## Declaration of Conformity

We:

**AXIS** Spółka z o.o. 80-125 Gdańsk, ul.Kartuska 375B

Confirm with all responsibility that AG and AGZ series balances:

*AG100, AG200, AG300, AG500*  
*AG600, AG1000, AG2000, AG3000, AG4000, AG8*  
*AGZ100, AGZ200, AGZ300, AGZ500*  
*and AGZ600, AGZ1000, AGZ2000, AGZ3000, AGZ4000, AGZ8*

marked with CE mark comply with the following:

1. EN 55022 standard *Limits and methods of measurement of radio disturbance characteristics of information technology equipment* and IEC 61000-4-3 Electromagnetic compatibility (EMC) - Part 4-3: Testing and measurement techniques - Radiated, radio-frequency, electromagnetic field immunity test, harmonised with the Council Directive 89/336/EEC.

Additionally AG series balances with following marking on the name plate:

- a sticker with two-digit number of the year in which the mark was affixed and the number of the Notified Body
- a green metrology sticker with "M" mark
- a protective seal affixed by the Notified Body



comply with requirements stipulated on the Type-Approval Certificate TCM 128/06-4428 and for verification to comply with:

2. En 45501 *Metrological aspects of non-automatic weighing instruments* harmonised with the Council Directive 90/384/EEC amended with 93/68/EEC.

### Additional information

- Conformity evaluation for the Council Directive 89/336/EEC were carried out by Laboratorium Badawcze Oddziału Instytutu Elektrotechniki w Gdańsku
- Type-Approval Certificate no. TCM 128/06-4428 was issued by Český Metrologický Institut Brno (Notified Body no. 1383).

Gdańsk, 15.01.2007

Per pro Director of AXIS Ltd:

Production Manager      Jan Kończak

A handwritten signature in black ink, appearing to read 'M. Kończak', is written over a horizontal line. Below the line, the word 'Signature' is printed.